



QuickStart Setup Guide for SimplicityCam (SC5i+, SC5z, SC5z AF)

Check The Contents



SC5z
SC5z AF

SC5i+



USB Cable



QuickStart
Guide



Soft Doc Mat
with 5i+ only*

* Soft Doc Mat included only with SC5i+

Your SimplicityCam comes bundled with video capture software to capture still images and video.


To download and install the most up to date version of the software go to our **Going Green** Installation Guide online.

You'll find Windows® and Mac OSX® software as well as videos to help you get a quick handle on how to use the SimplicityCam.

Enjoy!

Make USB Connection

Note, the SimplicityCam drivers will install when the camera is plugged in to the computer. No driver pre-installation is required. Simply wait a few minutes for Windows or OSX to install the drivers and report that the new hardware has been successfully installed.



To complete the setup and installation of your SimplicityCam please visit our **Going Green** Installation Guide online at www.recordexusa.com/mySimplicityCam.html

Copyright © 2012 RecordexUSA, Inc. All Rights Reserved.

Mac and Mac OSX are trademarks of Apple Inc., registered in the U.S. and other countries. Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

Recordex[®]
USA

Tips For Maximum Performance




The built in LEDs are designed to provide optimum lighting conditions. We recommend using the LEDs to provide even white lighting. **Press the LED+/- button** on the camera to adjust the LEDs.



The USB ports located on the front of most desktop computers are not suitable for using with a camera. For best performance plug your camera into a **USB port on the back of the computer.**



If you are not getting any camera image or if the image is out of focus or just not as crisp as you expected please try the following: make sure the Recordex USA camera is selected and the resolution is set to 1280x1024 or higher and for the SC5i+ and SC5z adjust the focus ring if needed to bring image in to clear focus. To select the device click on the  button and then apply your settings under Video Device 1:

Video Device 1

Video device:

Video size: ▼

5-Year Warranty!

LIMITED 5-YEAR WARRANTY RECORDEX USA SimplicityCam Document Camera ("Product")

What is my warranty? Recordex warrants to the original purchaser only that the Product will be free from defects in material and workmanship under normal use for a period of five (5) years from the date of original purchase.

How long does this warranty last? Five (5) years from the date of the original purchase.

Who is responsible for Shipping? You are responsible for shipping the Product to our Warranty Service Depot. Recordex will pay for return shipment of the repaired Product under warranty. Return shipment will be by ground service to the 48 contiguous US states. You are responsible for shipping to Alaska, Hawaii and any address outside of the United States. If the Product is repaired out of warranty then you are responsible for shipping both ways. Recordex is not responsible for any shipping damage that may occur in transit to the service depot.

Is There A Special Warranty for Educators?

Yes, Product used in a classroom or education setting is eligible for our Replacement Warranty Service. Make sure our customer service representative knows that the Product is in and educational setting and we will replace the product should a defect arise. Product will be replaced with new or refurbished product at Recordex's discretion. This process eliminates the wait time associated with sending in the Product for repair. This warranty is often referred to as a 'hot swap' warranty.

What must I do to obtain warranty service? To obtain warranty service please contact Recordex's Customer Service Center at 1-718-392-5380 x2 or contact your authorized Recordex Dealer for assistance in filing a warranty claim. You will receive instructions on how to properly return your product for authorized warranty repair. In order to receive warranty service you must be able to provide an original receipt or invoice for the purchase of your Product.

What are the limitations? Recordex's warranty shall not apply: (i) to any Product subjected to accident, misuse, neglect, alteration, acts of God, improper handling, improper transport, improper storage, improper use or application, improper installation, industrial or commercial use, improper testing or unauthorized repair; or (ii) to cosmetic problems or defects that result from normal wear and tear under ordinary use, and do not affect the performance or use of the product. If the Product develops a covered defect within the warranty period, Recordex will, at its option, either repair or replace the Product at no charge, provided that the Product is returned during the warranty period and this is your exclusive remedy and the entire liability of Recordex under this warranty. No warranty is made or implied as to the effectiveness or suitability of this product for your purposes.

THE ABOVE STATED WARRANTY IS EXCLUSIVE AND REPLACES ALL OTHER WARRANTIES EXPRESSED OR IMPLIED INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. RECORDEX WILL NOT BE HELD LIABLE FOR ANY OTHER DAMAGES OR LOSS INCLUDING INCIDENTAL OR CONSEQUENTIAL DAMAGES AND LOSS OF PROFITS OR REVENUES FROM WHATEVER CAUSE, INCLUDING BREACH OF WARRANTY OR NEGLIGENCE.

Tech Support & Service

Go to www.recordexusa.com/mySimplicityCam.html for links to manuals, instructional product videos, and frequently asked questions.

Contact technical support by phone or email:
718-392-5380 ext. 2

Software License Codes

Go to www.recordexusa.com/mySimplicityCam.html to download XSight HD Viewer. Your XSight HD Software License is:

place sticker here

IMPORTANT - DO NOT DISCARD